



MTS Criterion™ Series 40

Product Manual

be certain.

Copyright information

© 2011 MTS Systems Corporation. All rights reserved.

Trademark information

MTS is a registered trademarks and MTS Criterion and MTS Insight are trademarks of MTS Systems Corporation within the United States. These trademarks may be protected in other countries.

Proprietary information

Software use and license is governed by MTS' End User License Agreement which defines all rights retained by MTS and granted to the End User. All Software is proprietary, confidential, and owned by MTS Systems Corporation and cannot be copied, reproduced, disassembled, decompiled, reverse engineered, or distributed without express written consent of MTS.

Software validation and verification

MTS software is developed using established quality practices in accordance with the requirements detailed in the ISO 9001 standards. Because MTS-authored software is delivered in binary format, it is not user accessible. This software will not change over time. Many releases are written to be backwards compatible, creating another form of verification.

The status and validity of MTS' operating software is also checked during system verification and routine calibration of MTS hardware. These controlled calibration processes compare the final test results after statistical analysis against the predicted response of the calibration standards. With these established methods, MTS assures its customers that MTS products meet MTS' exacting quality standards when initially installed and will continue to perform as intended over time.

Publication information

MANUAL PART NUMBER	PUBLICATION DATE
100-231-445 A	January 2011

Contents

Technical Support 7

- How to Get Technical Support 7
- Before You Contact MTS Service Representative 7
- If You Contact MTS by Phone 8

Preface 11

- Before You Begin 11
- Conventions 12
 - Documentation Conventions 12

Safety 15

- General Safety Practices 15
- Safety Practices Before System Operation 16
- Safety Practices While the System Is in Operation 19
- Hazard Labels 20

Introduction 23

- About This Manual 23
- Inappropriate Use 23
- Description 24
 - Frame Controller 24
 - Software 24
- Load Frame Components 26
- Specifications 31
 - Common Specifications 32
 - Model Specifications 33
 - Dimensions 38

Installation 43

- Frame Location and Ventilation 44
- Leveling the Load Frame 45

Leveling the Table-Top Load Frame	45
Leveling the Floor-Standing Load Frame	46
Installing Optional Enclosures	47
Controller Connections	50
Connecting the Main Power	50
Installing Cables	51
Accessory Mounting Dimensions	61
Model C42 Accessory Mounting Dimensions	62
Model C43 Accessory Mounting Dimensions	64
Model C44 Accessory Mounting Dimensions	67
Model C45 Accessory Mounting Dimensions	70

Operation 73

Main Power Switch (I/O) and Emergency-Stop	74
Setting Crosshead Travel Limits	75
Crush Zone Hazards	77
Fixture Mounting	78
Load Cell Mounting	79
Handset Control	83

Maintenance 85

Routine Maintenance Overview Checklist	85
Other service	87

Troubleshooting 89

Decommissioning 91

Appendix 93

Additional Digital I/O Information	93
------------------------------------	----

Electromechanical Load Unit Maintenance and Service Logs 95

8 Hours/Daily	96
40 Hours/Weekly	97

2000 Hours	98
PC Maintenance and System Inspection	98
2000 Hours	99
System Checks	99
2000 Hours	100
Lubrication	100
2000 Hours	101
Frame and Work Area	101

Declaration of Conformity 103

Technical Support

How to Get Technical Support

Start with your manuals

The manuals supplied by MTS provide most of the information you need to use and maintain your equipment. If your equipment includes software, look for online help and README files that contain additional product information.

If you cannot find answers to your technical questions from these sources, you can use the Internet, e-mail, telephone, or fax to contact MTS for assistance.

Technical support methods

MTS provides a full range of support services after your system is installed. If you have any questions about a system or product, contact Technical Support in one of the following ways.

Outside the U.S.

For technical support outside the United States, contact your local sales and service office. For a list of worldwide sales and service locations and contact information, use the Global MTS link at the MTS web site:

www.mts.com > Global MTS > (choose your region in the right-hand column) > (choose the location closest to you)

Before You Contact MTS Service Representative

MTS can help you more efficiently if you have the following information available when you contact us for support.

Know your contact number and system number

The contact number contains your company number and identifies your equipment type (such as material testing or simulation). The number is typically written on a label on your equipment before the system leaves MTS. If you do not know your MTS contact number, contact your sales engineer.

When you have more than one MTS system, the system model number and series number identifies your system. You can find your these number in your order paperwork or directly on your equipment.

Identify the problem

Describe the problem and know the answers to the following questions:

- How long and how often has the problem occurred?
- Can you reproduce the problem?
- Were any hardware or software changes made to the system before the problem started?
- What are the equipment model numbers?
- What is the controller model (if applicable)?
- What is the system configuration?

If You Contact MTS by Phone

Know relevant computer information

For a computer problem, have the following information available:

- Manufacturer's name and model number
- Operating software type and service patch information
- Amount of system memory
- Amount of free space on the hard drive where the application resides
- Current status of hard-drive fragmentation
- Connection status to a corporate network

Know relevant software information

For software application problems, have the following information available:

- The software application's name, version number, build number, and (if available) software patch number. This information can typically be found in the **About** selection in the **Help** menu.
- The names of other applications on your computer, such as:
 - Anti-virus software
 - Screen savers
 - Keyboard enhancers
 - Print spoolers
 - Messaging applications

If You Contact MTS by Phone

A Call Center agent registers your call before connecting you with a technical support specialist. The agent asks you for your:

- Contact number
- Name
- Company name
- Company address
- Phone number where you can be reached

If your issue has a notification number, please provide that number. A new issue will be assigned a unique notification number.

Identify system type

To enable the Call Center agent to connect you with the most qualified technical support specialist available, identify your system as one of the following types:

- Electromechanical material test system
- Hydromechanical material test system
- Vehicle test system
- Vehicle component test system
- Aero test system

Be prepared to troubleshoot

Prepare to perform troubleshooting while on the phone:

- Call from a telephone close to the system so that you can implement suggestions made over the phone.
- Have the original operating and application software media available.
- If you are not familiar with all aspects of the equipment operation, have an experienced user nearby to assist you.

Write down relevant information

In case Technical Support must call you:

- Verify the notification number.
- Record the name of the person who helped you.
- Write down any specific instructions.

After you call

MTS logs and tracks all calls to ensure that you receive assistance for your problem or request. If you have questions about the status of your problem or have additional information to report, please contact Technical Support again and provide your original notification number.

Preface

Before You Begin

Safety first!

Before you use your MTS product or system, read and understand the *Safety* manual and any other safety information provided with your system. Improper installation, operation, or maintenance can result in hazardous conditions that can cause severe personal injury or death, or damage to your equipment and specimen. Again, read and understand the safety information provided with your system before you continue. It is very important that you remain aware of hazards that apply to your system.

Other MTS manuals

In addition to this manual, you may receive additional manuals in paper or electronic form.

Manuals located on the product information CD will contain information that pertains to your test system, such as:

- Hydraulic and/or mechanical accessory manuals
- Assembly drawings
- Parts lists
- Operation instructions
- Preventive maintenance tasks

Controller and application software manuals are typically included on the software CD distribution disc(s).

Conventions

Documentation Conventions

The following paragraphs describe some of the conventions that are used in your MTS manuals.

Hazard conventions

Hazard notices may be embedded in this manual. These notices contain safety information that is specific to the activity to be performed. Hazard notices immediately precede the step or procedure that may lead to an associated hazard. Read all hazard notices carefully and follow all directions and recommendations. Three different levels of hazard notices may appear in your manuals. Following are examples of all three levels.

Note Refer to “Safety” on page 15 for general safety information.



Danger notices indicate the presence of a hazard with a high level of risk which, if ignored, *will* result in death, severe personal injury, or substantial property damage.



Warning notices indicate the presence of a hazard with a medium level of risk which, if ignored, *can* result in death, severe personal injury, or substantial property damage.



Caution notices indicate the presence of a hazard with a low level of risk which, if ignored, *could* cause moderate or minor personal injury or equipment damage, or could endanger test integrity.

Notes

Notes provide additional information about operating your system or highlight easily overlooked items. For example:

Note *Resources that are put back on the hardware lists show up at the end of the list.*

Special terms

The first occurrence of special terms is shown in *italics*.

Illustrations

Illustrations appear in this manual to clarify text. They are examples only and do not necessarily represent your actual system configuration, test application, or software.

Electronic manual conventions

This manual is available as an electronic document in the Portable Document File (PDF) format. It can be viewed on any computer that has Adobe Acrobat Reader installed.

Hypertext links

The electronic document has many hypertext links displayed in a blue font. All blue words in the body text, along with all contents entries and index page numbers, are hypertext links. When you click a hypertext link, the application jumps to the corresponding topic.

Safety

General Safety Practices

This section provides information about safety issues that pertain to electromechanical systems in general. These issues include statements to the intended use and foreseeable misuse of the system, the hazard zone, definition for the graphical hazard labeling that is affixed to your product, and other (more general) safety information that relates to the high-performance characteristics of MTS Criterion electromechanical systems.

MTS Criterion test systems are designed to generate motions and forces and impart these motions and forces into a test specimen.

When you prepare to operate the system and during system operation, ensure the following:

- Do not use or allow personnel to operate the system who are not experienced, trained, or educated in the inherent dangers associated with high-performance electromechanical machines and who are not experienced, trained, or educated with regard to the intended operation as it applies to this test system.
- Do not disable safety components or features (including limit detectors, light curtains, or proximity switches/detectors).
- Do not attempt to operate the system without appropriate personal safety gear (for example, hearing, hand, and eye protection).
- Do not use specimens that are combustible, flammable, pressurized, or explosive.
- Whenever possible, use tongs or similar device to handle specimens during specimen installation.
- Do not use humans as specimens or allow humans to ride in or on the test specimen or the test system for any purpose unless the system is man-rated and all associated safety conditions are strictly enforced.
- Do not modify the system or replace system components using parts that are not MTS component parts or effect repairs using parts or components that are not manufactured to MTS specifications.
- Do not operate the system in an explosive atmosphere.
- Do not use the system in a test area where uncontrolled access to the test system is allowed when the system is in operation.

If you have system related responsibilities (that is, if you are an operator, service engineer, or maintenance person), you should study safety information carefully before you attempt to perform any test system procedure.

Safety Practices Before System Operation

You should receive training on this system or a similar system to ensure a thorough knowledge of your equipment and the safety issues that are associated with its use. In addition, you should gain an understanding of system functions by studying the other manuals supplied with your test system. Contact MTS for information about the content and dates of training classes that are offered.

It is very important that you study the following safety information to ensure that your facility procedures and the system's operating environment do not contribute to or result in a hazardous situation. Remember, you cannot eliminate all the hazards associated with this system, so you must learn and remain aware of the hazards that apply to your system at all times. Use these safety guidelines to help learn and identify hazards so that you can establish appropriate training and operating procedures and acquire appropriate safety equipment (such as gloves, goggles, and hearing protection).

Each test system operates within a unique environment which includes the following known variables:

- Facility variables (facility variables include the structure, atmosphere, and utilities)
- Unauthorized customer modifications to the equipment
- Operator experience and specialization
- Test specimens

Because of these variables (and the possibility of others), your system can operate under unforeseen circumstances that can result in an operating environment with unknown hazards.

Improper installation, operation, or maintenance of your system can result in hazardous conditions that can cause death, personal injury, or damage to the equipment or to the specimen. Common sense and a thorough knowledge of the system's operating capabilities can help to determine an appropriate and safe approach to its operation.

Safety Practices Before System Operation

Before you apply power to the test system, review and complete all of the safety practices that are applicable to your system. The goal, by doing this, is to improve the safety awareness of all personnel involved with the system and to maintain, through visual inspections, the integrity of specific system components.

Read all manuals

Study the contents of this manual and the other manuals provided with your system before attempting to perform any system function for the first time. Procedures that seem relatively simple or intuitively obvious can require a complete understanding of system operation to avoid unsafe or dangerous situations.

Locate and read hazard placards/labels

Find, read, and follow the hazard placard instructions located on the equipment. These placards are placed strategically on the equipment to call attention to areas such as known crush points and electrical voltage hazards.

Locate lockout/tagout points	Know where the lockout/tagout point is for all of the supply energies associated with your system. This includes the hydraulic, pneumatic, electric, and water supplies (as appropriate) for your system to ensure that the system is isolated from these energies when required.
Know facility safe procedures	Most facilities have internal procedures and rules regarding safe practices within the facility. Be aware of these safe practices and incorporate them into your daily operation of the system.
Locate Emergency Stop buttons	Know the location of all the system Emergency Stop buttons so that you can stop the system quickly in an emergency. Ensure that an Emergency Stop button is located within 2 meters (6 feet) of the operator at all times.
Know controls	Before you operate the system for the first time, make a trial run through the operating procedures with the power off. Locate all hardware and software controls and know what their functions are and what adjustments they require. If any control function or operating adjustment is not clear, review the applicable information until you understand it thoroughly.
Have first aid available	Accidents can happen even when you are careful. Arrange your operator schedules so that a properly trained person is always close by to render first aid. In addition, ensure that local emergency contact information is posted clearly and in sight of the system operator.
Know potential crush and pinch points	Be aware of potential crush and pinch points on your system and keep personnel and equipment clear of these areas.
Know electrical hazards	When the system electrical power is turned on, minimize the potential for electrical shock hazards. Wear clothing and use tools that are properly insulated for electrical work. Avoid contact with exposed wiring or switch contacts. Whenever possible, turn off electrical power when you work on or in proximity to any electrical system component. Observe the same precautions as those given for any other high-voltage machinery.
Keep bystanders safely away	Keep bystanders at a safe distance from all equipment. Never allow bystanders to touch specimens or equipment while the test is running.
Wear proper clothing	Do not wear neckties, shop aprons, loose clothing or jewelry, or long hair that could get caught in equipment and result in an injury. Remove loose clothing or jewelry and restrain long hair.
Remove flammable fluids from test specimen	Remove flammable fluids from their containers or from components before you install the container or component in a test system. If desired, you can replace the flammable fluid with a non-flammable fluid to maintain the proper proportion of weight and balance.
Check bolt ratings and torques	To ensure a reliable product, fasteners (such as bolts and tie rods) used in MTS manufactured systems are torqued to specific requirements. Over torquing or under torquing a fastener can create a hazardous situation due to the high forces and pressures present in MTS test systems.

Safety Practices Before System Operation

	<p>On rare occasions, a fastener can fail even when it is correctly installed. Failure usually occurs during torquing, but it can occur several days later. Failure of a fastener can result in a high velocity projectile. Therefore, it is a good practice to avoid stationing personnel in line with or below assemblies that contain large or long fasteners.</p>
Practice good housekeeping	<p>Keep the floors in the work area clean. Do not leave tools, fixtures, or other items not specific to the test, lying about on the floor, system, or decking.</p>
Protect hoses and cables	<p>Protect electrical cables from excessive temperatures that can cause the cables to harden and eventually fail. Ensure that all cables have appropriate strain relief devices installed at the cable and near the connector plug. Do not use the connector plug as a strain relief.</p> <p>Protect all system hoses and cables from sharp or abrasive objects that can cause the hose or cable to fail. Never walk on hoses or cables or move heavy objects over them. Consider system layout and route hoses and cables away from areas that expose them to possible damage.</p> <p>When removing hydraulic hoses for equipment repair or changing testing components (for example, hydraulic grips), make sure to cap the hose ends to avoid spilling hydraulic fluid.</p>
Record changes	<p>If you change any operating procedure, write the change and the date of the change in the appropriate manual.</p>
Provide test area guards	<p>Use protective guards such as cages, enclosures, and special laboratory layouts when you work with hazardous test specimens (for example, brittle or fragmenting materials or materials that are internally pressurized).</p>
Do not disable safety devices	<p>Your system might have active or passive safety devices installed to prevent system operation if the device indicates an unsafe condition. Do not disable such devices as it can result in unexpected system motion.</p>
Use appropriately sized fuses	<p>Whenever you replace fuses for the system or supply, ensure that you use a fuse that is appropriately sized and correctly installed. Undersized or oversized fuses can result in cables that overheat and fuses that explode. Either instance creates a fire hazard.</p>
Provide adequate lighting	<p>Ensure adequate lighting to minimize the chance of operation errors, equipment damage, and personal injury. You need to see what you are doing.</p>
Provide means to access out-of-reach components	<p>Make sure you can access system components that might be out of reach while standing on the floor. For example, ladders or scaffolding might be required to reach load cell connectors on tall load units.</p>
Ensure equipment is secure	<p>Make sure the equipment is secure or provide vibration isolation. Some testing can be performed at resonant frequencies that might cause the equipment to vibrate and move during testing.</p>
Periodically run consistency checks	<p>Pressing the Emergency-Stop button causes the system to automatically run a consistency check. The Emergency-Stop button should be pressed occasionally to run the consistency check.</p>

Safety Practices While the System Is in Operation

Wear appropriate personal protection	Wear eye protection when you work with electromechanical testing machines, breakable specimens, or when anything characteristic to the specimen could break apart.
	Wear ear protection when you work near electric motors, pumps, or other devices that generate high noise levels. Some systems can create sound pressure levels that exceed 70 dbA during operation.
	Wear appropriate personal protection equipment (gloves, boots, suits, respirators) whenever you work with fluids, chemicals, or powders that can irritate or harm the skin, respiratory system, or eyes.
Provide test area guards	Use protective guards such as cages, enclosures, and special laboratory layouts when you work with hazardous test specimens (for example, brittle or fragmenting materials or materials that are internally pressurized).
Expect specimen temperature changes	During cyclic testing, the specimen temperature can become hot enough to cause burns. Wear personal protection equipment (gloves) when handling specimens.
Handle chemicals safely	Whenever you use or handle chemicals (for example, cleaning fluids, hydraulic fluid, batteries, contaminated parts, electrical fluids, and maintenance waste), refer to the appropriate MSDS documentation for that material and determine the appropriate measures and equipment required to handle and use the chemical safely. Ensure that the chemical is disposed of appropriately.
Know system interlocks	Interlock devices should always be used and properly adjusted. Interlock devices are designed to minimize the chance of accidental damage to the test specimen or the equipment. Test all interlock devices for proper operation immediately before a test. Do not disable or bypass any interlock devices as doing so could allow crosshead movement regardless of the true interlock condition.
Know system limits	Never rely on system limits, such as mechanical limits or software limits, to protect you or any personnel. System limits are designed to minimize the chance of accidental damage to test specimens or to equipment. Test all limits for proper operation immediately before a test. Always use these limits and adjust them properly.
Do not disturb sensors	Do not bump, wiggle, adjust, disconnect, or otherwise disturb a sensor (such as an accelerometer or extensometer) or its connecting cable when power is applied.
Ensure secure cables	Do not change any cable connections when electrical power is applied. If you attempt to change a cable connection while the system is in operation, an open control loop condition can result. An open control loop condition can cause a rapid, unexpected system response which can result in severe personal injury, death, or damage to equipment. Also, ensure that all cables are connected after you make any changes in the system configuration.
Stay alert	Avoid long periods of work without adequate rest. In addition, avoid long periods of repetitious, unvarying, or monotonous work because these conditions can contribute to accidents and hazardous situations. If you are too familiar with the work environment, it is easy to overlook potential hazards that exist in that environment.

Hazard Labels

Stay clear of moving equipment/avoid crush points

Stay clear of mechanical linkages, connecting cables, and hoses that move because you can get pinched, crushed, tangled, or dragged along with the equipment. High forces generated by the system can pinch, cut, or crush anything in the path of the equipment and cause serious injury. Stay clear of any potential crush points. Most test systems can produce sudden, high-force motion. Never assume that your reactions are fast enough to allow you to escape injury when a system fails.

Know the causes of unexpected crosshead motions

The high force and velocity capabilities of MTS systems can be destructive and dangerous (especially if crosshead motion is unexpected). The most likely causes of unexpected crosshead response are operator error and equipment failure due to damage or abuse (such as broken, cut, or crushed cables and hoses; shorted wires; overstressed feedback devices; and damaged components within the control loop). Eliminate any condition that could cause unexpected crosshead motion.


Do not use RF transmitters

Keep radio frequency (RF) transmitters away from the workstation computers, remote terminals, and electronics consoles. Intense RF fields can cause erratic operation of the more sensitive circuits in the system.

Hazard Labels

The following hazard labels and icons are located on the test frame.

LABEL	DESCRIPTION
	Lift the machine upright.
	Moving parts present. Moving parts can crush and cut. Keep hands away from moving parts.

LABEL	DESCRIPTION
	<p>Flying objects. Danger of eye injury. Wear safety glasses.</p>
	<p>Tip over hazard. Use outriggers when machine is standalone.</p>
	<p>Do not start, operate, or service machine until you read and understand the operator's manual. Failure to do so could result in serious injury.</p>
	<p>There are no customer-serviceable parts on the MTS Criterion electromechanical frames.</p>
	<p>To turn the pulley, manually move the crosshead upward and downward. Pulleys can be turned by hand when power is disabled.</p>

WEEE

The Waste Electrical and Electronic Equipment (WEEE) symbol () means that the controller and its electronic parts must not be disposed of as unsorted municipal waste. Proper disposal is required by approved electronic waste collection agencies. Customers in the EC region who desire to return an end-of-life controller and its electronic parts are encouraged to contact your local MTS Systems Sales/Service Offices for instructions.

Introduction

About This Manual

Purpose The purpose of this manual is to help you understand your testing system, its capabilities, and operating requirements. This manual provides information for all MTS Criterion Series 40 Material Test System; From the lowest force model (5 kN), to the highest (100 kN). Read each section carefully and refer to the manual whenever you need assistance.

Inappropriate Use

Before you attempt to use the MTS Criterion Series 40 Material Test System, read and understand this manual. Improper installation or operation of this product can result in hazardous conditions that can cause severe personal injury or death, and damage your equipment and specimen.

Contents	Description	24
	Load Frame Components	26
	Specifications	31

Description

Every MTS Criterion Series 40 Material Test System is comprised of a load frame, electronic frame controller, and testing software.

The load frame has a rectangular shape and includes a base unit and one or two vertical columns. The two-column models have a fixed upper transverse beam. The moving crosshead is driven by precision ball screws on the load frame. The crosshead is coupled to the ball screw(s) with high-strength, precision ball nuts and rides on the ball bearings. This configuration is very efficient in minimizing friction and wear. The ball screws are preloaded. This feature removes the backlash so that position can be measured with increased accuracy over non-preloaded ball screws.

The load frame drive is located in the frame base. The drive motor is connected to the lower end of the ball screws by a series of belts and drive pulleys. On the two-column machines, motor rotation causes synchronous rotation of the ball screws, which causes the crosshead to move up or down. On the single-column machines, motor rotation causes the rotation of the single ball screw, which causes the crosshead to move up or down.

Frame Controller

The frame controller is responsible for the following:

- Provides main data and signal processing power.
- Detects the activation of limit switches.
- Provides the interface between the software (computer) and the frame.
- Provides digital servocontrol—for speed and position accuracy.
- Automatically identifies accessories, including load cells and extensometers, with the self-identify feature.
- Communicates with the handset.
- Provides programmable data acquisition rate (up to 1000 Hz maximum) .
- Commands the motor.

Software

MTS testing software has various method templates available. The method templates in the General Testing Package provide a starting point in configuring test methods that conform to your testing needs. The General Testing Package is separated into four specific testing categories:


- MTS Tensile
- MTS Compression
- MTS Flex
- MTS Peel-Tear

Many additional features can be purchased to meet your company's specific needs. Some of these features might already be part of the system you ordered, or they can be added to your system as your requirements change. Refer to the testing software manual for additional information.


Load Frame Components

The following figures show the various components for the single-column and two-column load frames. To familiarize yourself with the various components of your frame, refer to the figure that shows your model number.


For dimensions, see the specification tables in the “[Specifications](#)” on page 31.




Model C42 Maximum Rated Force Capacity 5 kN



Model C43 Maximum Rated Force Capacity 10 kN




Model C43 Maximum Rated Force Capacity 30 kN, 50 kN



Model C44 Maximum Rated Force Capacity 10 kN, 30 kN

Load Frame Components



Model C45 Maximum Rated Force Capacity 50 kN, 100 kN

Specifications

This section provides specifications for MTS Criterion Electromechanical Material Testing System frames and accessory mounting dimensions.

Note *Specifications are subject to change without notice. Contact MTS for verification of critical specifications.*

Common Specifications

The following specifications are for all MTS Criterion frames. Specifications for the specific models are located in the following tables.

CALIBRATION STANDARD	ISO 7500 CLASS 0.5 OR ASTM E4	ISO 7500 CLASS 1
Force range	1-100% of rated force capacity	0.5-1% of force rated capacity
Rated force capacity at max test speed	100%	
Maximum test speed at rated force capacity	100%	
Force indicating accuracy	± 0.5 % of indicating	
Speed accuracy	Set speed < 0.01 mm/min: speed accuracy is within ± 1.0% of set speed Set speed ≥ 0.01 mm/min: speed accuracy is within ± 0.2% of set speed	
Position accuracy	within ± 0.5%	
Strain accuracy	ASTM E83 or ISO 8513	
Security protection	Over-Force, travel limits, over-voltage and others	
Over force protection	10%	
Data acquisition rate	1000 Hz	
Control loop rate	1000 Hz	
Environmental requirements	For indoor use only	
Operating temperature	5-40°C (41-104°F)	
Operating humidity	5-85% Noncondensing	
Storage temperature	-18-49°C (0-120°F)	
Maximum storage humidity	90% Noncondensing	
Maximum altitude	2000 m (6562 ft)	
Motor and drive system	AC Servomotor	
Ball screws	Preloaded	
Position measurement	Encoder	
Additional DC conditioning channels	2 channels	
Additional incremental encoder conditioning channels	1 channel	

Model Specifications

Specifications of Model C42

PARAMETER	SPECIFICATION
Maximum rated force capacity	5 kN (1100 lbf)
Force capacity options	1 N, 5 N, 10 N, 25 N, 50 N, 100 N, 250 N, 500 N 1 kN, 2 kN, 5 kN 0.2 lbf, 1 lbf, 2 lbf, 5 lbf, 10 lbf, 20 lbf, 50 lbf, 110 lbf 220 lbf, 450 lbf, 1100 lbf
Frame type	1 Guide column, table-top
Test zone	Single
Maximum test speed	2000 mm/min (78.7 in/min)
Minimum test speed	0.005 mm/min (0.0002 in/min)
Position resolution	0.00005 mm (0.000002 in)
Vertical test space crosshead travel	
Standard length	650 mm (25.6 in)
Extended length	950 mm (37.4 in)
Clearance from loading axis to column cover	100 mm (3.94 in)
Frame height	
Standard length	1296 mm (51 in)
Extended length	1596 mm (62.83 in)
Frame width	700 mm (27.56 in)
Frame depth	632 mm (24.88 in)
Weight	
Standard length with enclosure	160 kg (352 lb)
Standard length without enclosure	129 kg (284 lb)
Extended length with enclosure	178kg (392 lb)
Extended length without enclosure	143 kg (315 lb)
Power Requirements	200-230 V AC 5 Amp 50/60 Hz 1000 W 1 Phase

Specifications of Model C43 (part 1 of 2)

PARAMETER	SPECIFICATION		
Maximum rated force capacity	10 kN	30 kN	50 kN
Force capacity options	100 N, 250 N, 500 N, 1 kN, 2.5 kN, 5 kN, 10 kN	100 N, 250 N, 500 N, 1 kN, 2.5 kN, 5 kN, 10 kN, 20 kN, 30 kN	100 N, 250 N, 500 N, 1 kN, 2.5 kN, 5 kN, 10 kN, 20 kN, 30 kN, 50 kN
	20 lbf, 50 lbf, 110 lbf, 220 lbf, 500 lbf, 1100 lbf, 2200 lbf	20 lbf, 50 lbf, 110 lbf, 220 lbf, 500 lbf, 1100 lbf, 2200 lbf, 4400 lbf, 6600 lbf	20 lbf, 50 lbf, 110 lbf, 220 lbf, 500 lbf, 1100 lbf, 2200 lbf, 4400 lbf, 6600 lbf, 11000lbf
Frame type	2 Guide columns Table-top	2 Guide columns Table-top	2 Guide columns Table-top
Test zone	Single	Single	Single
Maximum test speed	2000 mm/min (78.7 in/min)	1020 mm/min (40.16 in/min)	750 mm/min (29.53 in/min)
Minimum test speed	0.005 mm/min 0.0002 in/min	0.005 mm/min 0.0002 in/min	0.005 mm/min 0.0002 in/min
Position resolution	0.00005 mm 0.000002 in	0.00006 mm 0.0000024 in	0.00006 mm 0.0000024 in
Vertical test space crosshead travel			
Standard length	1000 mm (39.37 in)	1000 mm (39.37 in)	1000 mm (39.37 in)
Extended length	1300 mm (51.18 in)	1300 mm (51.18 in)	1300 mm (51.18 in)
Space between columns	425 mm (16.73 in)	420 mm (16.54 in)	420 mm (16.54 in)
Frame height			
Standard length	1591 mm (62.64 in)	1739 mm (68.46 in)	1739 mm (68.46 in)
Extended length	1891 mm (74.45 in)	2039 mm (80.28 in)	2039 mm (80.28 in)
Frame width	794 mm (31.26 in)	826 mm (32.52 in)	826 mm (32.52 in)
Frame depth	757 mm (29.8 in)	768 mm (30.24 in)	768 mm (30.24 in)

Specifications of Model C43 (part 2 of 2)

Weight			
Standard length with enclosure	224 kg (493 lb)	371 kg (816 lb)	371 kg (816 lb)
Standard length without enclosure	184 kg (405 lb)	328 kg (722 lb)	328 kg (722 lb)
Extended length with enclosure	244 kg (537 lb)	396 kg (872 lb)	396 kg (872 lb)
Extended length without enclosure	196 kg (431 lb)	345 kg (759 lb)	345 kg (759 lb)
Power requirements			
	200-230 V AC	200-230 V AC	200-230 V AC
	10 Amp	12 Amp	12 Amp
	50/60 Hz	50/60 Hz	50/60 Hz
	2000 W	2400 W	2400 W
	1 Phase	1 Phase	1 Phase


Specifications of Model C44

PARAMETER	SPECIFICATION	
Maximum rated force capacity	10 kN	30 kN
Force capacity options	100 N, 250 N, 500 N, 1 kN, 2.5 kN, 5 kN, 10 kN	100 N, 250 N, 500 N, 1 kN, 2.5 kN, 5 kN, 10 kN, 20 kN, 30 kN
	20 lbf, 50 lbf, 110 lbf, 220 lbf, 500 lbf, 1100 lbf, 2200 lbf	20 lbf, 50 lbf, 110 lbf, 220 lbf, 500 lbf, 1100 lbf, 2200 lbf, 4400 lbf, 6600 lbf
Frame type	2 Guide columns Floor-standing	2 Guide columns Floor-standing
Test zone	Single or Dual	Single or Dual
Maximum test speed	2000 mm/min (78.7 in/min)	1020 mm/min (40.16 in/min)
Minimum test speed	0.005 mm/min (0.0002 in/min)	0.005 mm/min (0.0002 in/min)
Position resolution	0.000049 mm (0.0000019 in)	0.00006 mm (0.0000024 in)
Vertical test space crosshead travel		
Standard length	1000 mm (45.28 in)	1000 mm (45.28 in)
Extended length	1300 mm (51.18 in)	1300 mm (51.18 in)
Space between columns	400 mm (15.75 in)	400 mm (15.75 in)
Frame height		
Standard length	1930 mm (75.98 in)	1930 mm (75.98 in)
Extended length	2230 mm (87.80 in)	2230 mm (87.80 in)
Frame width	864 mm (34.02 in)	864 mm (34.02 in)
Frame depth	694 mm (27.32 in)	694 mm (27.32 in)
Weight		
Standard length with enclosure	435 kg (957 lb)	445 kg (979 lb)
Standard length without enclosure	399 kg (878 lb)	409 kg (900 lb)
Extended length with enclosure	458 kg (1008 lb)	468 kg (1030 lb)
Extended length without enclosure	415 kg (913 lb)	425 kg (935 lb)
Power requirements	200-230 V AC	200-230 V AC
	10 Amp	12 Amp
	50/60 Hz	50/60 Hz
	2000 W	2400 W
	1 Phase	1 Phase


Specifications of Model C45

PARAMETER	SPECIFICATION	
Maximum rated force capacity	50 kN	100 kN
Force capacity options	1 kN, 2.5 kN, 5 kN, 10 kN, 20 kN, 30 kN, 50 kN	1 kN, 2.5 kN, 5 kN, 10 kN, 20 kN, 30 kN, 50 kN, 100 kN
	220 lbf, 500 lbf, 1100 lbf, 2200 lbf, 4400 lbf, 6600 lbf, 11000 lbf	220 lbf, 500 lbf, 1100 lbf, 2200 lbf, 4400 lbf, 6600 lbf, 11000 lbf, 22000 lbf
Frame type	2 Guide columns Floor-standing	2 Guide columns Floor-standing
Test zone	Single or Dual	Single or Dual
Maximum test speed	750 mm/min (29.53 in/min)	750 mm/min (29.53 in/min)
Minimum test speed	0.005 mm/min (0.0002 in/min)	0.005 mm/min (0.0002 in/min)
Position resolution	0.000047 mm (0.0000019 in)	0.000047 mm (0.0000019 in)
Vertical test space crosshead travel		
Standard Length	1000 mm (39.37 in)	1000 mm (39.37 in)
Extended Length	1300 mm (51.18 in)	1300 mm (51.18 in)
Space between columns	600 mm (23.62 in)	600 mm (23.62 in)
Frame height		
Standard length	2265 mm (89.17 in)	2265 mm (89.17 in)
Extended length	2565 mm (100.98 in)	2565 mm (100.98 in)
Frame width	1316 mm (51.81 in)	1316 mm (51.81 in)
Frame depth	957 mm (37.68 in)	957 mm (37.68 in)
Weight		
Standard length with enclosure	1398 kg (3076 lb)	1398 kg (3076 lb)
Standard length without enclosure	1350 kg (2970 lb)	1350 kg (2970 lb)
Extended length with enclosure	1436 kg (3160 lb)	1436 kg (3160 lb)
Extended length without enclosure	1380 kg (3036 lb)	1380 kg (3036 lb)
Power requirements	200-230 V AC	200-230 V AC
	12 Amp	22 Amp
	50/60 Hz	50/60 Hz
	2400 W	4400 W
	1 Phase	1 Phase


Dimensions




Model C42 Maximum Rated Force Capacity 5 kN




Model C43 Maximum Rated Force Capacity 10 kN



Model C43 Maximum Rated Force Capacity 30 kN, 50 kN



Model C44 Maximum Rated Force Capacity 10 kN, 30 kN



Model C45 Maximum Rated Force Capacity 50 kN, 100 kN

Installation

Contents	Frame Location and Ventilation	44
	Leveling the Load Frame	45
	Installing Optional Enclosures	47
	Controller Connections	50
	Accessory Mounting Dimensions	61

Frame Location and Ventilation

To ensure proper ventilation, locate the load frame approximately 300 mm (12 inches) from adjacent walls and equipment. Allow approximately 1 m (3 feet) behind the equipment for service access. Do not block the vent holes on the sides or bottom of the frame.

For comfortable working conditions and proper equipment operation, heat dissipation of the equipment must be considered in providing adequate heating or air conditioning in the laboratory area. Heat dissipation can be approximated by summing the heat losses going into a room (1 kVA is equivalent to 860 kcal/hr [3,400 Btu/hr]) and the gains from other sources such as furnaces and personnel.

Leveling the Load Frame

Leveling the Table-Top Load Frame


Level the table-top load frame immediately after you position it for installation. This prevents the base from rocking and provides a level test surface for more accurate test results.

Equipment The following items are required:

- Spirit or bubble level
- Open-end wrench

Procedure To level the frame base:

1. Place a spirit or bubble level on the center of the base beam.
2. Loosen the top nut on each leveling foot.
3. Using an open-end wrench, alternately adjust the height of each leveling foot while you monitor the spirit or bubble level reading.
4. Rotate the spirit or bubble level 90° to verify that the load frame is level side to side and front to back.
5. When the machine is level, tighten the top nut on each leveling foot.



Leveling the Floor-Standing Load Frame


Level the load frame immediately after you position it for installation. This prevents the base from rocking and provides a level test surface for more accurate test results.

Equipment The following items are required:

- Spirit or bubble level
- Socket wrench
- M8 hex key wrench for C44 model
- M10 hex key wrench for C45 model

Procedure To level the frame base:

1. Place a spirit or bubble level on the center of the base beam.
2. Loosen the top nut on each leveling foot using the socket wrench.
3. Using an M14 hex key wrench, alternately adjust the height of each leveling foot while you monitor the spirit or bubble level reading.
4. Rotate the spirit or bubble level 90° to verify that the load frame is level side to side and front to back.
5. When the machine is level, tighten the top nut on each leveling foot using the socket wrench.




Installing Optional Enclosures

Customer must evaluate risks due to ejected parts or materials from the test specimens. If Test Area Guard is not selected by customer, then for protection against ejected parts or materials from test specimens and to control access to the machinery, the Customer must provide a Test Area Guard to protect personnel.


Every MTS Criterion Series 40 Material Test System has an optional test area enclosure. The optional enclosure is comprised of front and back enclosures and can enclose the test space completely.

When shipping, front door and back door of enclosure are removed from the frame and packaged separately. After the frame is placed in its testing location, you need to install front door and back door of enclosure.

Install front door on hinges and check for proper alignment of safety switch-adjust as needed. Rear door does not use a safety switch, but is latched with a 6 mm bolt (using a 5 mm hex wrench to tighten).



Installing Front Door of Enclosure



Installing Back Door of Enclosure

Controller Connections

Connecting the Main Power

5 kN through 100 kN

The input voltage of MTS Criterion frames rated 100 kN or less is single phase 200-230 V, 50/60 Hz.

Note *Local electrical codes supercede any information found here.*

For MTS Criterion frames equal or less than 10 kN, use 3 holes type I socket (C13 style on the Criterion) for power input, specification of power wire is H05VV-F, 3G1 mm², compatible with standards of KEMA-KEUR, CEBEC, +S+S+S, VDE, SABS, IEMMEQU for certification.

For MTS Criterion frames more than 10 kN, use the 3-wires cable that is provide for power input, and connect to the customer electrical box and disconnect. The type of power cable is listed below:

- 10 kN~50 kN - HO7RN-F 3G2.5 mm², compatible with standards of ELOT, PECSO for certification.
- 100 kN - HO7RN-F 3G4 mm², compatible with IEMMEQU, PECSO for certification.

Note *Electrical connections must be made by qualified personnel and is their responsibility for using the proper power disconnect that conforms to local codes and regulations when connecting the machine to the buildings main power.*

Electrical disconnect

The customer is responsible for providing an electrical power disconnect that is easy to operate and easy to reach. It must also meet IEC 60947-1 and IEC 60947-3 standards.

Recommended circuit breaks would be ones that are of the thermal magnetic type with characteristics suitable for large inductive loads (D-type trip characteristic). If fuses are used it is recommended that they are of the time delay type with dual elements. These recommendations should be followed to avoid nuisance tripping.

Installing Cables

Exercise care when connecting cables. Ensure that you are using the correct cables and that all connections are secure. When you are finished, double-check to ensure that all components are connected properly.


To maintain EMC compliance and help ensure optimal performance, MTS recommends ordering all system cables from MTS. Cables should be installed so that they are protected from conditions that could damage the cable.

CAUTION

There is dangerous voltage inside the machine.

Connecting cables with power applied can cause damage to the equipment.

Ensure that the power is turned off before connecting cables.



Controller connectors

J1 USB

This is a standard USB 2.0 connector that accepts a USB-B cable connector and connects to the computer. This provides a communications interface between the testing software on the PC and the controller. This is used to allow the software to change settings in the controller and to receive data from the controller.

J2 Handset


This is intended to interface to the handset. Specifics for this connector are:

- 12 V output power with 200 mA current limit
- RS422 driver (differential)
- RS422 receiver (differential)
- Interlock input. Handset shorts between INTLK+ and INTLK- when it is connected.
- 8-pin RJ-45 connector

PIN	SIGNAL
1	Transmit+
2	Transmit-
3	+12 V
4	INTLK+
5	INTLK-
6	Analog GND
7	Receive+
8	Receive-

J3 Interlock

J3 is intended for remote interlock connection. If not used, jumper plug P/N 049-635-901 must be installed to enable system interlocks to be cleared.



J4 Encoder

This connector is intended for encoder-based transducers. Specifics for this connector are:

- Power: +5 V +/- 0.25 V at 100 mA max
- Signals: Quadrature A and B with index I
- Logic: Differential receivers (can connect single ended)
- Maximum Rate: 100,000 lines/sec = 400,000 counts/sec

Pin assignments are as follows:

PIN	SIGNAL
1	TEDS data
2	A+
3	A-
4	+5 V
5	I+
6	I-
7	Analog GND
8	B+
9	B-
10	TEDS ground

J5 Digital I/O

The J5 connector routes the Digital I/O from the insight control board to J12 on the MTS Criterion interface board. The pin assignment below is only for reference. The cable from J5 to J12 must be connected for system operation.

PIN	SIGNAL
1	DIN1+
2	DIN2+
3	DIN3+
4	DOUT1+
5	DOUT2+
6	DOUT3+
7	No Contact
8	+12 V
9	DIN1-
10	DIN2-
11	DIN3-
12	DOUT1-
13	DOUT2-
14	DOUT3-
15	Analog GND

J6 and J7 Monitor

Two monitor connectors are provided. There are several possible uses for analog monitor outputs: external data acquisition, tuning, troubleshooting, and so forth. For tuning, it is desirable to monitor command and feedback, or command and error, simultaneously while changing the controller parameters. Therefore, two monitor outputs are provided. Specifics for these connectors are:

- Analog +/-10.5 V
- Calibrated to +/-10 V
- 16-bit resolution minimum
- BNC connectors

J8 and J9 DC Conditioner

Two external DC conditioner connectors are provided. Up to two external transducers can be connected such as: axial or transverse extensometers, biaxial extensometer, auxiliary load cells, pressure gages, LVDTs (with external conditioning), or strain-gaged components.

PIN	SIGNAL
1	TEDS data
2	EX+
3	EX-
4	FB-
5	RCAL1 (FBR+)
6	RCAL2 (FBR-)
7	FB+
8	EXS-
9	EXS+
10	TEDS ground

J10 Aux Pw1

The connector is the auxiliary Power connector. It can provide power to external devices. Pin assignments are as follows:

PIN	SIGNAL	
1	+12 V	400 mA (max combined with Pin 6)
2	AGND	
3	-12 V	400 mA max
4	PGND	
5	+5 V	400 mA max
6	+12 V	400 mA (max combined with Pin 1)
7	AGND	
8	DGND	
9	+24 V	400 mA max

J11 Guard

The connector should be connected to the safety system (Enclosure switch) or jumpered for crosshead motion.

Enclosure switch has two NC contacts. One must be connected between Pin 1 and Pin 6. The other must be connected between Pin 2 and Pin 7.

GUARD_CONFIG1/2-jumpers determine if crosshead motion slows to 540 mm/min or comes to a complete stop when the enclosure door opens. That is to say,

No Jumpers = complete stop with door open

Jumpers from Pin3-Pin8 and Pin5-Pin9 = crosshead slows to 540 mm/min with the enclosure door open.

PIN	SIGNAL
1	GUARD1A+
2	GUARD2A+
3	GUARD_CONFIG1+
4	No Contact
5	GUARD_CONFIG2-
6	GUARD1A -
7	GUARD2A-
8	GUARD_CONFIG1
9	GUARD_CONFIG2+

J12 Digital I/O Insight

The J12 connector routes the Digital I/O from the MTS Insight control board to J5 on the MTS Criterion interface board. The pin assignment below is only for reference. The cable from J12 to J5 must be connected for system operation.

PIN	SIGNAL
1	VCC
2	No Contact
3	DOUT3+
4	DOUT2+
5	DOUT1+
6	DIN3+
7	DIN2+
8	DIN1+
9	GND
10	DOUT3-
11	DOUT2-
12	DOUT1-
13	DIN3-
14	DIN2-
15	DIN1-

J13 Digital I/O User

Digital I/O signals include three optically isolated inputs, three optically isolated outputs, and 12 V power. Functions of each digital input or output are software selectable. A typical example might be connecting an external switch; see [“Additional Digital I/O Information”](#) on page 146. Only DIN1 and DOUT2 & 3 are available for external use. DIN2 & DOUT1 are used for Fault Status communications with the software. DIN3 is used for Enclosure door switch status. Pin assignments are as follows:

Note *If the optional enclosure is not used, DIN3 is still required by the control system to bypass the low-speed safety system.*

PIN	SIGNAL
1	DIN1+
2	DIN2+
3	DIN3+
4	DOUT1+
5	DOUT2+
6	DOUT3+
7	No Contact
8	VCC
9	DIN1-
10	DIN2-
11	DIN3-
12	DOUT1-
13	DOUT2-
14	DOUT3-
15	Analog GND


J14 E- Stop

This connector is intended to connect to a remote Emergency-Stop switch. If not used, a jumper plug must be installed. If you are building a cable, the maximum length is 30.48 m (100 ft) with 18 AWG. The switch should be wired normally closed, such that when the switch is pressed, an interlock is generated. Pin assignments are as follows:

- ESTOP3 = emergency stop switch with two sets of contacts (optional remotely mounted).
- ESTOP_OUT = optional ESTOP output for accessory, includes two contact outputs and one feedback. For use with pneumatic/hydraulic grip controls, furnaces, environmental chambers, and so on.

PIN	SIGNAL
1	ESTOPB_OUT-
2	No Contact
3	ESTOP_OUT_MONITOR-
4	ESTOP_OUT_MONITOR+
5	ESTOP3B+
6	ESTOPA_OUT-
7	ESTOP3B-
8	ESTOP3A+
9	ESTOPB_OUT+
10	No Contact
11	No Contact
12	No Contact
13	ESTOP3A-
14	ESTOPA_OUT+
15	No Contact

Crosshead load cell connector



For a single-testing zone material testing system, there is a connector for the load cell under the crosshead on one of the columns. For an optional dual-testing zone material testing system, there is a connector for the load cell under the top beam on one of the columns and there are two connectors for the load cell under the crosshead on one of the columns. When using the upper testing zone, the upper load cell is connected to the connector under the top beam on the one of columns, and the two connectors under the crosshead are connected by a jumper cable. When using the lower testing zone, the lower load cell is connected to the back one of two connectors under the crosshead. Pin assignments are as follows:

PIN	SIGNAL
1	EX+
2	EX-
3	No Contact
4	FB+
5	FB-
6	No Contact
7	SHIELD
8	TEDS+
9	No Contact
10	EXS+
11	No Contact
12	RCAL1 (FBR+)
13	RCAL2 (FBR-)
14	TEDS-
15	EXS-


Accessory Mounting Dimensions

You can attach numerous testing accessories and fixtures to the load frame for specialized tests. The following figures show the standard mounting holes in each style of load frame. Use these standard mounting holes to mount your accessories. Avoid tapping new holes that may weaken or otherwise compromise the integrity of the load frame. The following sections describe each style of load frame separately. Look for the section pertaining to your specific model for the appropriate dimensions.

Note *All measurements in the following figures are shown in mm.*


Model C42 Accessory Mounting Dimensions

Base beam




Model C42 Base Beam Mounting Dimensions

Crosshead



Model C42 Crosshead Mounting Dimensions


Top beam




Model C42 Top Beam Mounting Dimensions

Model C43 Accessory Mounting Dimensions

Base beam




Model C43 (10 kN) Base Beam Mounting Dimensions




Model C43 (30 kN, 50 kN) Base Beam Mounting Dimensions

Crosshead




Model C43 (10 kN) Crosshead Mounting Dimensions




Model C43 (30 kN, 50 kN) Crosshead Mounting Dimensions

Top beam




Model C43 (10 kN) Top Beam Mounting Dimensions



Model C43 (30 kN, 50 kN) Top Beam Mounting Dimensions


Model C44 Accessory Mounting Dimensions

Base beam




Model C44 Base Beam Mounting Dimensions

Crosshead




Model C44 Topside of Crosshead Mounting

Model C44 Accessory Mounting Dimensions




Model C44 Underside of Crosshead Mounting

Top beam




Model C44 Topside of Top Beam Mounting Dimensions



Model C44 Underside of Top Beam Mounting Dimensions


Model C45 Accessory Mounting Dimensions

Base beam




Model C45 Base Beam Mounting Dimensions

Crosshead




Model C45 Topside of Crosshead Mounting

Model C45 Accessory Mounting Dimensions




Model C45 Underside of Crosshead Mounting Dimensions

Top beam



Model C45 Topside of Top Beam Mounting Dimensions



Model C45 Underside of Top Beam Mounting Dimensions

Operation

This section describes the actions performed during normal, day-to-day operation of the MTS Criterion frame. For information on using the MTS Criterion frame in actual testing, refer to the testing software manual.

Contents	Main Power Switch (I/O) and Emergency-Stop	74
	Setting Crosshead Travel Limits	75
	Crush Zone Hazards	77
	Fixture Mounting	78
	Load Cell Mounting	79
	Handset Control	83

⚠ CAUTION

There are rotating parts inside the machine.

Operating the machine without side covers or bellows in place can expose the operator to rotating parts that could cause injury if contact is made.

Do not operate the MTS Criterion test frame without the side covers and bellows in place.

⚠ CAUTION

Specimen debris can enter the side covers and puncture bellows causing erratic machine operation.

Material fragments can puncture the bellows and damage the ball screw.

Damaged bellows should be replaced before operating the MTS Criterion Test Frame. Be aware of the potential of material fragments puncturing the bellows and damaging the ball screw, and be aware of the material properties and the hazards generated by the materials during testing. See [“General Cleaning”](#) on page 86.

⚠ WARNING

There are potential hazards during material testing.

Hazards generated by the materials during testing can cause injury or death.

Ensure that only qualified, trained personnel should be allowed to operate the machine. Keep bystanders away during machine operation.

Main Power Switch (I/O) and Emergency-Stop

Main power switch (I/O)

The main power switch is located on the right side of the frame base. Select position **I** to turn the power on to the load frame and the controller. When the power is on, the displays on the frame control panel illuminate. Select position **O** to turn off power to the load frame and the controller.



Emergency Stop

The frame is also equipped with an **Emergency Stop** button. The **Emergency-Stop** will cut the power to the motor and should be used for emergency purposes only.

The **Emergency-Stop** should be periodically pressed when the controller is powered but not when a test is running. The controller continuously monitors the redundant **Emergency-Stop** chain and will generate a fault alerting the user if any problems are detected. Pressing **Emergency-Stop** allows the active state to be checked.

To shut down the motor power and stop the test program, press the **Emergency-Stop** button. Twist the switch clockwise to release it. Use the **Emergency-Stop** button to shut down your test if something unexpected should happen.



Setting Crosshead Travel Limits

There are two levels of crosshead limit stops that act to protect the crosshead from traveling too far in either direction. The first-level stops are the upper and lower limit stops that you manually set as described below. The second-level limits are not user adjustable and act as a backup in case the first-level limits malfunction.

CAUTION

The limit stops are not intended to be an end of test condition to end every test.

Repeated use of the limit stops in this way may cause excessive wear, which can result in the limit stop failing to stop the crosshead. Refer to the Warning below for more information on unexpected crosshead motion. Proper end of test conditions can be set from the software.

Do not use limit stops to end a test.

Crosshead Limit Stops

WARNING

Unexpected crosshead motion can occur during testing.

Failure to set the limit stops could cause injury from unexpected crosshead motion, and cause possible damage to test fixtures.

Always set the limit stops before starting a test.

Note *Set the crosshead limit stops after you establish the crosshead starting position, but before you start the test.*


The travel limit stops are two adjustable blocks mounted on the limit switch rod, which is located inside the column of the machine. Limit stops have thumbscrews that you tighten and release by hand, and you can move them to any position on the limit rod. Position these stops just beyond the test parameters to prevent crosshead over-travel. When the crosshead reaches the maximum pre-set travel, the limit switch actuator contacts one of these stops. Contact between the limit actuator and the limit stop moves the limit switch rod and activates the limit switches. This stops crosshead motion.

Setting the limit stops

To set the limit stops:

1. Ensure that the crosshead is stationary and that the test parameters are set.
2. Set the upper limit stop at a position just above the expected maximum crosshead travel in the upward direction when tension testing, or just above the test starting point when compression testing. Tighten the stop securely on the limit rod.

3. Set the lower limit stop at a position just below the starting position when tension testing or just below the expected maximum crosshead travel in the down direction when compression testing. Tighten the stop securely on the limit rod.



Moving the crosshead

When the crosshead contacts either the upper or lower limit stop, the test stops. If this happens, there are three ways to get the crosshead moving:



Resetting while in a limit disables the hardware interlock and allows motion.


If the hardware has failed, the crosshead could move unexpectedly.

The hardware is reset as soon as the crosshead has moved out of the limit.

- Press **Motor Reset** in TestWorks 4 software. Then use the crosshead capabilities of your software (virtual handset). Move the crosshead away from the limit until the switch closes and the crosshead can move in both directions again. See the TestWorks software manual for further details.
- Manually move the adjustable limit along the range of travel away from the crosshead until the limit switch is no longer active. Then press **Motor Amp Reset** in TestWorks 4 software or **Handset Enable** on the handset.
- If TestWorks 4 software is not active, press **Handset Enable** on the handset. Then use the manual handset control to move the crosshead until the limit switch is no longer active.

Crush Zone Hazards

It is important to stay clear of any potential crush zones when the system is operating. Know where the crush zones are in your system and protect yourself and others from those crush zones with appropriate safety devices. The following paragraphs describe crush zones and precautions to take while working around crush zones.




Locations A crush zone exists between the platen and crosshead on load units where the crosshead and specimen move (both areas are shown).

Precautions Keep clear of any mechanical linkage that moves within a closed area. If the linkage should move (when the system starts or due to mechanical failure), very high forces can be present that could pinch, cut, or crush anything in the path of linkage movement.

Never allow any part of your body to enter the path of machine movement or to touch moving machinery, linkages, hoses, cables, specimens, and so forth. These present serious crush points or pinch points.

Fixture Mounting

MTS offers a wide variety of fixtures. Mounting these fixtures typically involves installing the fixture or load cell onto a mounting (clevis pin) adapter and securing it with a mounting dowel (pin). To further secure a fixture, some configurations also include locking collars. A typical mounting configuration is shown in the following figure.




Load Cell Mounting


Mounting load cells typically involves securing the load cell to the frame via a threaded bolt along with associated hardware (in most cases a flat washer, adapter sleeve, and plate assembly). The following figures show the standard mounting configurations. Load cell mounting/adaptor bolts should be lubricated with light oil or grease before being assembled and torqued to specifications. See [“Load Cell Bolt Torque Specifications”](#) on page 82.

When installing a mounting bolt or an adapter bolt into load cell, check the length of bolt to avoid “bottoming” the bolt in the load cell hole. Doing so will permanently damage the load cell.


On C42 S-beam style cells, support the grip adapter while torquing the adapter bolt to prevent damaging the load cell from torque twist.




Model C42 1 N-5 kN




Model C43 10 kN




Model C43 20 kN, 30 kN



Model C43 50 kN



Model C44 10 kN, 20 kN and 30 kN



Model C45 50 kN and 100 kN


Load Cell Bolt Torque Specifications

LOAD CELL	TYPE	BOLT THREAD	LUBE AND TORQUE TO:	WRENCH SIZE
1 N	S-Beam	M3	5 N•m	M2 hex
5 N-250 N	S-Beam	M6 x 1 mm	5 N•m	M5 hex
500 N-2 kN	S-Beam	M6 x 1 mm	10 N•m	M5 hex
5 kN	S-Beam	M12 x 1.25 mm	20 N•m	M10 hex
100 N- 500 N	Low Profile Bending Beam	M6 x 1 mm	10 N•m	M5 hex
1 kN- 5 kN	Low Profile Shear Beam	M12 x 1.25 mm	20 N•m	M10 hex
10 kN	Low Profile Shear Beam	M12 x 1.25 mm	40 N•m	M10 hex
20 kN	Low Profile Shear Beam	M12 x 1.25 mm	65 N•m	M10 hex
30 kN	Low Profile Shear Beam	M12 x 1.25 mm	90 N•m	M10 hex
50 kN and 100 kN	Low Profile Shear Beam	M27 x 2 mm	27 N•m *	M6 hex

* Torque supernut jackbolts to the torque specified in the table in a crisscross pattern. Bring jackbolts to 33% of full torque, then bring to 66% of full torque, and then to 100% full torque.

Handset Control

The handset has an encoder and buttons to help you during specimen installation and test execution. The handset also has an alphanumeric display and LEDs to provide feedback.



Handset functions The handset is intended to be used for specimen loading or setup. In some applications, it can be used to completely run a test.

Handset Controls and Indicators (part 1 of 2)

#	CONTROL/INDICATOR	DESCRIPTION
1	Page	Displays the next four lines of text in the display.
2	Active	When lit, indicates the system is active (motion is possible).
3	F1 and F2	Programmable functions that are set up in the software as digital inputs. This allows you to define the test function (that is, start test, pause, hold position, and so forth).
4	Thumb-wheel	Makes fine crosshead adjustment (towards display – up; away from display – down. <i>Only if Handset Enable is active.</i>
5	Pause	Pauses the test action. This must be pressed again for the test to resume. <i>Only if the testing software is active.</i>
6	Stop	Stops motion.

Handset Controls and Indicators (part 2 of 2)

7	Connector	RJ-45, to Controller.
8	Crosshead Return	Returns the crosshead to the original position (zero point).
9	Start	Starts the test action. <i>Only if the testing software is active.</i>
10	Crosshead Down	Moves the crosshead in the downward direction while depressed. <i>Only if Handset Enable is active.</i>
11	Crosshead Up	Moves the crosshead in the upward direction while depressed. <i>Only if Handset Enable is active.</i>
12	Fault	When lit, indicates an active fault or interlock.
13	Handset enable	Pressing with an interlock active attempts to clear the interlock. Pressing when there are no active interlocks enables the handset for local control. When the indicator is lit, the handset is enabled for control of the crosshead.
14	Display	Four lines, 20 characters per line.

Maintenance

Routine Maintenance Overview Checklist

Recommended Service

CALENDAR TIME USING 8 HOURS RUNNING TIME RATE PER DAY	DAILY	WEEKLY	ANNUALLY
RUNNING TIME-HOURS	8	40	2000
Check shunt calibration	X*		
Clean work area/machine surface	X		
Activate and reset limits and Emergency-Stop		X	
Inspect cable/connections		X	
PC Maintenance			
Back up testing software files (*.reg/.cal files)			MTS†
Hard drive defragment			MTS
System Inspection			
Check/adjust drive belt tension (refer to table)			MTS
Inspect drive belts for excessive wear			MTS
Inspect cable connections			MTS
System Checks			
Check Emergency-Stop			MTS
Check upper limit			MTS
Check lower limit			MTS
Check load cal/shunt cal			MTS
Lubrication			
Crosshead/ball screw (#2 white lithium grease)			MTS
Guide column zerk fittings			MTS
Drivetrain bearings (if applicable)			MTS
Frame and Work Area			
Clean off frame and work area			MTS

* Denotes services performed by equipment operators. Most of these procedures involve visual checks that should not interfere with testing system operation. These checks are also completed by trained field service engineers on each Routine Maintenance visit.

† Denotes service performed by trained field service engineers as part of an MTS Routine Maintenance plan. Some of these procedures require special service tools and/or specific service training to complete.

There are no customer serviceable components on the MTS Criterion frames. Maintenance consists of keeping the frame and work area clean, general inspection, checking interlocks, and scheduled frame calibration.

⚠ WARNING

Be careful not to spill and cleaning liquid on the frame.

Inadvertent electrical component contamination with detergents or cleaning fluids can cause circuits to short resulting in equipment damage.

Disconnect the power cord from the wall outlet before cleaning or inspecting any part of the test frame.

⚠ CAUTION

Observe all manufacturers recommendations and cautions when using any cleaning solution.

Cleaning solution can cause damage to injury.

To avoid hazardous conditions, always follow the manufacturers' recommendations and cautions.

General Cleaning

Clean the frame as often as needed. Use a damp, lint-free rag to clean the side covers, base, and crosshead. If necessary, mild detergent or cleaning fluid can be used.

Monthly Maintenance

Verify that the **Emergency Stop** button is functioning properly.
Test the limit switches by manually moving the adjustable limits—a limit switch fault should be indicated on the computer screen.
Verify any additional interlocks are functioning properly (for example, the interlock switches on the door of a test area enclosure).

Semiannual Maintenance

Verify the speed and position accuracy of the frame. This requires standards and other equipment typically not available for routine maintenance. Contact your MTS field service engineer for assistance.


Removing Mats

Some installation and maintenance situations may require you to remove the load frame mat covers in order to access components within the base of machine. To remove the mat of the C42 model:

1. Using a ball-end 5 mm hex driver, remove the two M6 bolts holding the upper horizontal aluminum extrusion on the rear guard and remove the extrusion.
2. Remove the upper profile from the safety enclosure frame.
3. Gently remove the clear polycarbonate from the safety enclosure and place it in a safe place.
4. Use the ball-end 5 mm hex key driver to loosen the two M6 bolt connectors on the lower horizontal aluminum extrusion.

5. Remove the lower profile from the safety enclosure frame.
6. Open the front door, and carefully remove the rubber mat, as the rubber mat can tear at the corners.

To install the mat, please perform the procedures in reverse.



Removing the Mat of C42 Model

Other service

Regular inspection and service of the drive motor system and crosshead positioning components are needed to prolong the life of your frame and keep it performing optimally. This type of service is typically preformed by MTS field service engineers or MTS authorized service representative. Contact your MTS authorized representative for additional information.

Note MTS offers annual maintenance and calibration plans. Contact your sales representative for more information.

Troubleshooting

Basic Troubleshooting

SYMPTOMS	SOLUTIONS
Failure in Windows system	<p>Turn off the computer and start again.</p> <p>Check to see if the failure is gone; if the failure still exist, ask your IT Department to check into the problem. If your IT Department can't solve the issue, delete the current windows system and install it again.</p> <p>If after the re-install the issue still exists, contact the local service center of the computer manufacturer directly or via MTS China, to repair the computer.</p>
Testing software failure	<p>Displacement cannot be cleared or displayed. Normally, it is caused by an incorrect sequence in turning on testing system; shut off the software and restart it.</p> <p>If restarting does not solve the problem, delete the testing software, and install the software again.</p>
Communication trouble between hardware and software	<p>Check all cable connections.</p> <p>If communication between the PC and the Criterion system are not working try the following:</p> <ul style="list-style-type: none">• Remove the USB connector from the Criterion system and plug it back in and see if communications starts between the two.• Shut off power to the Criterion system and turn it on again, see if communication starts between the two.
Power OK light not on when power switch is on	<p>Check that:</p> <ul style="list-style-type: none">• The power cable is plugged in.• The line voltage is within specified machine limits.
Cannot clear interlocks	<p>Check:</p> <ul style="list-style-type: none">• If Emergency-Stop is active.• For system interlocks (servo error, limits).• For system faults.

Decommissioning

The decommissioning process is performed when the system is going to be moved or taken out of service. Disassembly is required when performing either of these tasks.

To decommissioning the system:

1. Remove specimen and fixtures. Large grips should be removed if the load frame could be tipped over.
2. Isolate the system from electrical power.
3. When the system electronics, control software, and the system PC are powered down, turn off the system's main electrical supply and disconnect all cables.
4. Disconnect all cables from the controller.
5. Cover the material testing machine with a dust cover, such as plastic foil. Allow for sufficient ventilation or place a dehumidifier near to the equipment.
6. Place the accessories and the instruction manual in a clean, dust protected place, such as a tool cabinet.



Electrical components and parts can contain hazardous chemicals and compounds.

Always refer to local codes that govern the disposal of potentially hazardous materials and follow these codes for the proper handling and disposal of these materials.


Customer should follow internal safety policies for safe disposal of parts of the machine. Refer to MSDS for oils and greases that are used on the machine.

Appendix


Additional Digital I/O Information

The digital inputs have an MOCD223 optical isolator with 2.7 Kohm, ½ Watt series resistor. To reliably turn on, they need 1 mA of current. This means the minimum input high voltage is 4.0 V DC. The maximum input voltage is 28.0 V DC. The device should be off for input voltages less than 1.0 V.

The digital outputs are implemented by an AQV252G PhotoMOS relay with a 0.75 Amp poly fuse in series. Although the device is rated at 60 V peak, it is recommended that a maximum of 48 V be applied. If the load is highly inductive, such as a relay coil, an appropriate snubber network should be used near the coil terminals to prevent large flyback voltages from exceeding the device ratings.



A typical example might be connecting an external switch.



Electromechanical Load Unit Maintenance and Service Logs

Contents	8 Hours/Daily	96
	40 Hours/Weekly	97
	2000 Hours	98
	PC Maintenance and System Inspection	98
	System Checks	99
	Lubrication	100
	Frame and Work Area	101

Declaration of Conformity



MTS Systems Corporation
 14000 Technology Drive
 Eden Prairie, MN 55344-2290
 Telephone 952-937-4000
 Fax 952-937-4515

ORIGINAL

DECLARATION OF CONFORMITY IN ACCORDANCE WITH ANNEX II 1A OF COUNCIL DIRECTIVE 2006/42/EC	
Equipment Identification:	
CRITERION ELECTROMECHANICAL MATERIAL TESTING SYSTEMS	Serial No. (select one only)
C42, C42EL	
C43, C43EL	
C44, C44EL	
C45, C45EL	
Optional Equipment Name / Model	Serial No. (or other similar identification. If Serial No. or identification is not available, then check X to denote delivery)
Test Area Guard	
634.XX extensometer	
632.XX extensometer	
LX laser extensometer	
xLT Hi elongation extensometer	
Tempsonics	
661.XX Load cell	
662.XX Load cell	
663.XX Torque cell	
660.2X Load cell	
660.2X delta P cell	
Fundamental Environmental Chamber	
658 Enviro Bath	
652.XX Hi-temperature furnace	
653.XX Hi-temperature furnace	
409 Temperature Controller	
647.XX Hydraulic wedge grips	
643.XX compression platens	
642.XX bend fixture	
640.XX fracture mechanics grip	
Advantage Pneumatic grip	
Advantage screw action grip	
Advantage wedge grip	
Fundamental Bollard grip	
Fundamental Cord / yarn grip	
Fundamental Roller grip	
Fundamental Scissors grip	
Fundamental Vise grip	
Advantage and Fundamental Pneumatic grip controller	
Equipment Description:	
The MTS CRITERION ELECTROMECHANICAL MATERIAL TESTING SYSTEMS (C42, C43, C44 AND C45) 50 N to 100 kN with TestWorks Software is intended to perform testing of materials and components, including plastics, metals, composites, adhesives, textiles, wood and paper products, ceramics, elastomers, and foam. Includes the following sub-systems of the machine: Frame, Motor, Amplifier, Controller, Handset and Cables. Customer must evaluate risks due to ejected parts or materials from the test specimens. If Test Area Guard is not selected by customer, then for protection against ejected parts or materials from test specimens and to control access to the machinery, the Customer must provide a Test Area Guard to protect personnel.	

Manufacturer: MTS Systems Corporation 14000 Technology Drive Eden Prairie, MN 55344-2290, U.S.A.	
Authorized Representative: Stefan Strand MTS Systems Norden AB Södra Långebergsgatan 16 SE-421 32 Västra Frölunda, Sweden	
Applicable Directive(s): Machinery Safety Directive 2006/42/EC Low Voltage Directive 2006/95/EC EMC Directive 2004/108/EC	
Harmonized or Other Standards Referenced: EN ISO 12100-2 Safety of machinery - Basic concepts, general principles for design - Part 2: Technical principles EN 61010-1: Safety requirements for electrical equipment for measurement, control and laboratory use, Part 1: General requirements EN 61326-1: Electrical equipment for measurement, control and laboratory use EMC requirements Part 1: General requirements EN 55011 Industrial, scientific and medical (ISM) radio-frequency equipment — Electromagnetic disturbance characteristics — Limits and methods of measurement Group 1: class A (non-domestic where RF is NOT used in the treatment of material)	
Technical Construction File in accordance with Annex VII Part A: A copy (electronic and paper) of the Technical Construction File for this machinery is available on request from: Authorized Representative	
We, MTS Systems Corporation, hereby declare that the machinery described above conforms with the relevant provisions of Annex I Essential Health and Safety Requirements of Directive 2006/42/EC and that the Annex VIII Conformity Assessment Procedure has been carried out.	
Place of Issue:	Eden Prairie, MN 55344, USA
Date of Issue:	
Signature:	
Name and Title:	Rich Baker, Vice President (Engineering)



MTS Systems Corporation
<http://www.mts.com/en/Global/index.asp>

ISO 9001 Certified QMS